


ENDON®

Eterne LED Table Light INSTRUCTION MANUAL

Safety Warnings

- This product is only suitable for connection to a 240V~50Hz supply in accordance with current IEE Wiring Regulations. It is for indoor use only, and not suitable for a bathroom location.
- This product is Class 3 (low voltage)  and uses a plug-in transformer. Under no circumstances must this be replaced by a standard 13amp UK type plug. This will cause a safety hazard.
- If the mains cable becomes damaged it must only be replaced by a technically competent, qualified person. In the case of a Class III rated product, a new cable set may be available - please check with your retailer.
- Do not plug into the mains until your lamp is fully assembled.
- Under no circumstances must this table lamp be covered with any material as this could pose a safety hazard. It must be used on a stable, flat surface.
- This product contains non-replaceable LEDs. If the LEDs become damaged the whole unit must be replaced.
- If you are in any doubt about your competence please consult a qualified electrician.
- If any modification is made it will invalidate the warranty and may render the product unsafe.

Care Information

Allow 10 minutes to cool before adjusting or cleaning.

Clean with a dry cloth only. Do not use liquid or abrasive cleaners on this product.


Assembly/ User Instructions

Before you start

Please read these instructions carefully before fitting and retain for reference. Check the packaging and make sure that you have all the required parts. Follow each assembly step in order to prevent incorrect assembly. Ensure that the product is fully assembled before use.

These assembly diagrams are intended as a guide. If in doubt, please consult a qualified electrician.

1. Carefully unpack your lamp, and place your lamp on a stable, flat surface.
2. Connect the driver to the product. Plug in the LED driver.
3. Operate the switch to turn on. This product is fitted with a push button memory dimmer switch. It remembers the last setting when switched on or off.



If your lamp will not illuminate, please check the relevant fuse in your fuse box. If unsuccessful please consult your retailer.